


Front View




- 1) Frame 75 c/w frame screw (15), frame gasket
- 2) Door 75R c/w , bottle bar, door gasket 75R, door pad, panel (black or white) *Not Shown*, door rod
- 3) Hinge Assembly c/w hinge bearing, hinge left, hinge right, hinge pin (2), hinge screw (12)
- 4) Thumb Latch c/w thumb latch, latch pin, latch spacer
- 5) Shelf 75
- 6) Thermostat Assembly c/w knob, case, wire 45 (grey)
- 7) Evaporator 75R c/w suction line, armafex
- 8) Evaporator 75F c/w capillary tube, suction line, armafex
- 9) Drip Tray 75R **not shown**
- 10) Drip Tray 75F **not shown**
- 11) Freezer Door 75 c/w door gasket 75F
- 12) Latch 75 c/w male & female ends, screws (4)
- 13) Light Assembly c/w light base, light wire, light switch, light
- 14) Crisper c/w crisper handle **not shown**
- 15) Crisper Shelf 75 c/w crisper support bracket & aluminum bar
- 16) Accessory Bag c/w ice cube tray, manual, mounting hole plugs (4) **not shown**

Back View



- 1) Condenser 75 c/w mounting clips & screws
- 2) Pipe Insulation
- 3) Base 26 c/w screws
- 4) bd3.5f Compressor c/w rubber feet (4), compressor clip (4)
- 5) Fridge Drier
- 6) Electronic AC/DC* c/w red wire 11, black wire 11
- 7) AC Receptacle c/w fuse 4, wire harness,
- 8) AC Cord 115 optional 220
- 9) Cabinet 75
- 10) Fan Assembly c/w fan12, fan bracket
- 11) Speed Resistor (Optional) No resistor=low speed, black resistor=medium speed, red resistor=high speed



Base Expanded View

Notes:

* DC models electronic 2000 replaces electronic AC/DC